

AST Bulk Storage

Emergency Vent (Threaded or Flanged)



Allows tank to exhaust excessive pressure if exposed to pool fire. Size to be determined by tank size and type.

Internal Emergency Valve




Automatic shut-off of product flow in event of fire and/or impact. Poppet is located inside tank.

Gate Valve with Expansion Relief



Expansion Relief feature allows excess pressure due to temperature gain to bleed back to tank.

Frost Proof Drain Valve




Allows water on bottom of tank to be drained off. Seat is located up inside the tank shell.

Normal (P/V) Vent - and with Flame Arrestor



Allows tank to breathe during normal filling and withdrawing operations. Match vent size to fill and withdrawal piping.



Morrison Bros. Co.
 Established 1855
 800.553.4840 • 563.583.5701 • 563.583.5028 (fax)
 custserv@morbro.com • www.morbro.com